



# IMPROVED CERTIFICATIONS SEARCH TOOL. REGISTER NOW!

[LEARN MORE](#)

WYMV.E146589

## Telemetering Equipment for Use in Hazardous Locations

[Page Bottom](#)

## Telemetering Equipment for Use in Hazardous Locations

[See General Information for Telemetering Equipment for Use in Hazardous Locations.](#)

**BARKSDALE INC**  
3211 FRUITLAND AVE  
VERNON, CA 90058-3717 USA

E146589

Trademark and/or Tradename: "Automation-X, Corporation", "X-Mitter"

**Class I, Division 1, Groups A, B, C and D; Class II, Division 1, Groups E, F, and G pressure transducers,** Model(s) H455X, 455X, 452X may be followed by T6, followed by -23, -01, -21, -03, -22, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, -17, -18, -29, -30, -31, -32, -33, may be followed by A, B, BA, may be followed by -P6, -P4, -P5, -P10, -P11, -P13, -P3, -P1, -P2, -P14, -P15, may be followed by -ZVxx, -Z17, -SS, -SC, -UL, -A1, -Zxxy, -Wxxx

**Class I, Division 2, Groups A, B, C, and D; Class II, Division 2, Groups F and G, pressure transducers,** Model(s) 435, 433 and 436 followed by -H5, -H5E, followed by -01, 03, -04, -05, -06, -07, -08, -10, 11, -12, -13, -14, -15, -16, -17, -18, -19, -21, -22, -23, or -25, may be followed by -Z10, -Z11, -Z12, or -Z15, -W, or -4 digits, may be followed by A may be followed by P1 through P10, or by Q1 through Q999.

**Class I, Division 2, Groups A, B, C, and D; Class II, Division 2, Groups F and G, pressure transducers,** Model(s) 443 and 446, followed by -H5 or -H5E, -T8, -T8-E, followed by -01, -03, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, -17, -18, -19, -21, -22, -23 or -25, may be followed by Z10, -Z11, -Z12, -Z15, -Z16, -Z17 or -Z18, -W or -4 digits, may be followed by A, may be followed by P1 through P10 or by Q1 thru Q999.

**Class I, Division 2, Groups A, B, C, and D; Class II, Division 2, Groups F and G, pressure transducers,** Model(s) 445, followed by -H5 or -H5E, -T8, -T8-E, followed by -01, -03, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, -17, -18, -19, -21, -22, -23 or -25, may be followed by - or -Z15 or -Z17, -W or -4 digits, may be followed by A, may be followed by P1 through P10 or by Q1 thru Q999.

**Class I, Groups A, B, C and D; Class II, Groups E, F and G, position indicators, intrinsically safe when installed in accordance with control drawing no. 272263,** Model(s) 371MT73, 371MT75

**Class I, groups A, B, C and D; Class II, Groups E, F and G, pressure transducers,** Model(s) 425X, followed by -01, -03, -04, -05, -06, -07, -08, -10, -12, -13, -14, -15, -16, -17, -18, -19 or -22, may be followed by -A.

**Class I, groups A, B, C and D; Class II, Groups E, F and G, pressure transducers, for use in Class I, groups A, B, C and D; Class II, Groups E, F and G Hazardous Locations,** Model(s) 423X, 425X, 426X, followed by -01, -03, -04, -05, -06, -07, -08, -10, -12, -13, -14, -15, -16, -17, -18, -19, -21, or -22, -23 or -25, may be followed by -A suffix, may be followed by -P1, -P3, -P4, -P5, -P6, -P7, -P10, -P11 or -P12 suffix, may be followed by -Z, -W, -Q1 thru Q999 suffix, may be followed by additional digits, may be followed by - S.

**Class I, Groups A, B, C and D; Class II, Groups E, F and G, pressure transmitters, intrinsically safe when installed in accordance with Control Drawing No. 272147,** Model(s) 446, followed by -H3, -H3-E, -H5, -H5E, -H6, -H6-E, -T4, -T4-E, -T5, -T5-E, -T8, -T8-E, followed by -01, -03, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, 17, -18, -19, -21, -22, -23, or -25, may be followed by -Z10, -Z11, -Z12, -Z15, -Z16, -Z17 or -Z18, -W or -4 digits, may be followed by A, may be followed by P1 through P10, or by Q1 thru Q999.

**Class I, Groups A, B, C and D; Class II, Groups E, F and G, pressure transmitters, intrinsically safe when installed in accordance with Control Drawing No. 272148,** Model(s) 443, followed by -H3, -H3-E, -H5, -H5E, -H6, -H6-E, -T4, -T4-E, -T5, -T5-E, -T8, -T8-E, followed by -01, -03, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, 17, -18, -19, -21, -22, -23, or -25, may be followed by -Z10, -Z11, -Z12, -Z15, -Z16, -Z17 or -Z18, -W or -4 digits, may be followed by A, may be followed by P1 through P10, or by Q1 thru Q999.

**Class I, Groups A, B, C and D; Class II, Groups E, F and G, pressure transmitters, intrinsically safe when installed in accordance with control drawing no. TD-B77,** Model(s) 445, followed by -H3, -H3-E, -H5, -H5E, -H6, -H6-E, -T4, -T4-E, -T5, -T5-E, -T8, -T8-E, followed by -01, -03, -04, -05, -06, -07, -08, -10, -11, -12, -13, -14, -15, -16, 17, -18, -19, -21, -22, -23, or -25, may be followed by -Z15 or -Z17, -W or -4 digits, may be followed by A, may be followed by P1 through P10, or by Q1 thru Q999.

[Last Updated](#) on 2018-12-05

[Questions?](#)

[Print this page](#)

[Terms of Use](#)

[Page Top](#)

© 2018 UL LLC

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL's Follow-Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL's Follow-Up Service. Always look for the Mark on the product.

UL permits the reproduction of the material contained in the Online Certification Directory subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from the Online Certifications Directory with permission from UL" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "© 2018 UL LLC".